



IB-100 Instructions

3 Easy steps and you're done!

Visit WWW.INKBLASTER.COM for Video Demo

UV Inks:

1. Wipe Anilox & Metering rolls down to remove excess ink before cleaning.
2. Apply IB-100 to a heavy-duty paper towel and wipe over surface until clean.
3. Dry with a clean rag or heavy-duty paper towel.

Use IB-100 full strength or dilute up to 30% with water.

Water Base:

Use IB-100 full strength or dilute as needed

IB-100 can be used on plates, ultra-sonic cleaners, floor scrubbers, and entire press area as an ink cleaner and floor scrubber.

- DO NOT soak aluminum parts
- Wear gloves. IB-100 is a safe product but will dry out skin

*Questions call 513-753-7888